Step	Action	Display
1	Power On Champion Pro	
2	On your Smart Phone Go To Settings	William Stander Service Servic
3	Open WiFi Connections and Select GNSS-Your Serial Number	WI-FI Direct ADVANCED ON ATTS14 Commented GNSS-1038760 + Add network

Step	Action	Display
4	To Connect to WiFi Enter Password 1-8	GNSS-1038760 Password 12345678 Show password Auto reconnect CANCEL CONNECT 1 2 3 4 5 6 7 8 9 0 q w e r t y u i o p a s d f g h j k l z x c v b n m Z x c v b n m
5	Screen should display a message telling you the Internet may be available	The residence of the re
6	Close Connections and Open Internet Browser. Enter IP Address 192.168.1.1	The properties of the properti

Step	Action	Display
7	You should See This Screen asking for LogIn Account And Password	© 192.168.1 throadine company)
8	LogIn Account = admin Password = password Check Remember Me if you wish to not enter UN and PW each time	CNSS Logn Account administration in the state of the stat
9	You should now be taken to the screen shown at the right	O 192168.1.1/mobile cample/rade [] [O to 198188/100 Status

Step	Action	Display
10	You can now check Status for Position and Activity if so desired	O 192 568 1 Annables compared on State State Fraction Activity O State Particles O State O S
11	You can also access the SkyPlot of Satellites being Tracked	SAMSUNG 192.168.1.1/mobile simple / web 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
12	To Run a Static Session, First Go To Satellites, Satellite Activation	SAMSUNG 192.108.71./mabble-simple/inde 6 Satellites Satellites Pack Setellites Pack Setellites Asteristion Fifty work mode Gastellite Activation Gastellite Activation Gastellite Activation Gastellite Activation Gastellites Activation

Step	Action	Display
13	Turn Off BDS and Galileo by moving the slide to the left. This will disable the Beidou and Galileo for recording of Static Observations	SAMSUNO 192.168.1.1/mobile-simplat/web GOPS GALLED BBAS Contract Cont
14	Next Go To static Recording	SANSUNG 192 168 1.1/mobile sample/node 9 192 168 1.1/mobile sample/node 9 Status Status Status Status Status Status Status Other conding Other centings Changuages Other centings
15	Move the Slides to the Right to Start the Receiver in Static Mode. The default parameters are 30 second epochs (Used for OPUS) and Rinex 2.11 File Format.	SAMSUND O 192.168.1.1/mobile-simples/verb Activate or Note Activate or Note Activate Nask To Destino Translateurity 1440 Distrino Translateurity 1450 Distrino Translateurity 1650 Distrino Translateurity 1650 Distrino Translateurity 1650 Distrino Translateurity Distrino Translate

Step	Action	Display
16	You can name your project and set your antenna height in the receiver	SAMSUNG O 192-168-1.1 (recolab examplativate) O 192-168-1.1 (recolab examplativate) I I I I I I I I I I I I I I I I I I I
17	You can also change the Epoch Interval and Elevation Mask	SAMSURG O 190 Stall 1 Procedure Sample Annual Delivery of the Sam
18	End Static Recording, Move the Slides to the Left, or Power down the Receiver. Remember to Disconnect from your Smart Phone WiFi. Downloading of Static Data will be covered in the next Chapter.	SAMEUNG 10 192.168.1.1/mobile-simplin/ento