Step	Action	Display
1	Power On Champion Pro	
2	On your Smart Phone Go To Settings	WITH THE PART OF T
3	Open WiFi Connections and Select GNSS-Your Serial Number	WI-FI WI-FI DIVEST ADVANCED ON ATTS14 Commented GNSS-1038760 + Add network

Step	Action	Display
4	To Connect to WiFi Enter Password 1-8	GNSS-1038760 Password 12345678 Show password Auto reconnect CANCEL CONNECT 1 2 3 4 5 6 7 8 9 0 q w e r t y u i o p a s d f g h j k l z x c v b n m Z x c v b n m
5	Screen should display a message telling you the Internet may be available	The residence of the re
6	Close Connections and Open Internet Browser. Enter IP Address 192.168.1.1	The properties of the properti

Step	Action	Display
7	You should See This Screen asking for LogIn Account And Password	© 192.168.1 throadine company)
8	LogIn Account = admin Password = password Check Remember Me if you wish to not enter UN and PW each time	CNSS Logn Account administration in the state of the stat
9	You should now be taken to the screen shown at the right	O 192168.1.1/mobile cample/rade [] [O to 198188/100 Status

Step	Action	Display
10	You can now check Status for Position and Activity if so desired	O 192.568 1 Armadase companional III : State France Activity O Statellars O Birk more mode O Statellars O Mick Acres August O Mick Statellars Mick Statellar
11	You can also access the SkyPlot of Satellites being Tracked	SAMSUNG 192.168.1.1/mobile simple / web 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
12	To Run a Static Session, First Go To Satellites, Satellite Activation	SANSUNG Discontinuous and first 2 control Discontinuous Satellites Batellites Tread Setellite Activation Giff Work mode Stellic recording MMARATS output Consist Registration Firmware C. Languages Other settings

Step	Action	Display
13	Turn Off BDS and Galileo by moving the slide to the left. This will disable the Beidou and Galileo for recording of Static Observations	SAMSUNO 192.168.1.1/mobile-sumple/web Proc GAMASS GAMASS
14	Next Go To static Recording	SAMSUNG 192168.17/mobile sample roads 9 status Status Status Status Status Status Other conding Child recording
15	Move the Slides to the Right to Start the Receiver in Static Mode. The default parameters are 30 second epochs (Used for OPUS) and Rinex 2.11 File Format.	SAMSUNG 192.168.13.1/mbble-simples/web Activate of Nut: Activate of Nut: Activate of Nut: Activate of Nut: District Mask 19 District Temphanaty 1449 District Temphanaty 1007700 200700000000000000000000000000

Step	Action	Display
16	You can name your project and set your antenna height in the receiver	SAMSUNG O 192-168-1.1 (recolab examplativate) O 192-168-1.1 (recolab examplativate) I I I I I I I I I I I I I I I I I I I
17	You can also change the Epoch Interval and Elevation Mask	SAMSURG O 190 Stall 1 Procedure Sample Annual Delivery of the Sam
18	End Static Recording, Move the Slides to the Left, or Power down the Receiver. Remember to Disconnect from your Smart Phone WiFi. Downloading of Static Data will be covered in the next Chapter.	SAMEUNG 10 192.168.1.1/mobile-simplin/ento